

Service Manual

TABLE OF CONTENTS

	PAGE
SAFETY CONSIDERATIONS	1
INTRODUCTION.....	1
MODEL NUMBER NOMENCLATURE	2
SPECIFICATIONS	3
DIMENSIONS	4
CLEARANCES.....	6
ELECTRICAL DATA	7
WIRING.....	7
CONNECTION DIAGRAM.....	8
WIRING DIAGRAM.....	9
FAN AND MOTOR SPECIFICATIONS.....	11
REFRIGERATION CYCLE DIAGRAM.....	11
REFRIGERANT LINES.....	12
SYSTEM EVACUATION AND CHARGING.....	12
OPERATION MODES AND FUNCTIONS.....	13
ERROR DIAGNOSIS AND TROUBLESHOOTING WITHOUT ER- ROR CODE.....	20
QUICK MAINTENANCE BY ERROR CODE.....	24
TROUBLESHOOTING BY ERROR CODE.....	25
DIAGNOSIS AND SOLUTION.....	27
DISASSEMBLY INSTRUCTIONS.....	40
APPENDICES.....	64

SAFETY CONSIDERATIONS

Installing, starting up, and servicing air-conditioning equipment can be hazardous due to system pressures, electrical components, and equipment location (roofs, elevated structures, etc.).

Only trained, qualified installers and service mechanics should install, start-up, and service this equipment.

Untrained personnel can perform basic maintenance functions such as cleaning coils. All other operations should be performed by trained service personnel.

When working on the equipment, observe the precautions in the literature and on tags, stickers, and labels attached to the equipment.

Follow all safety codes. Wear safety glasses and work gloves. Keep a quenching cloth and fire extinguisher nearby when brazing. Use care in handling, rigging, and setting bulky equipment.

Read this manual thoroughly and follow all the warnings or cautions included in literature and attached to the unit. Consult local building codes and National Electrical Code (NEC) for special requirements.

Recognize safety information. This is the safety-alert symbol . When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury. Understand these signal words: **DANGER**, **WARNING**, and **CAUTION**.

These words are used with the safety-alert symbol. **DANGER** identifies the most serious hazards which will result in severe personal injury or death. **WARNING** signifies hazards which could result in personal injury or death. **CAUTION** is used to identify unsafe practices which may result in minor personal injury or product and property damage. **NOTE** is used to highlight suggestions which will result in enhanced installation, reliability, or operation.


WARNING

ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury or death.

Before installing, modifying, or servicing the system, the main electrical disconnect switch must be in the **OFF** position. There may be more than 1 disconnect switch. Lock out and tag switch with a suitable warning label.


WARNING



EXPLOSION HAZARD

Failure to follow this warning could result in death, serious personal injury, and/or property damage.

Never use air or gases containing oxygen for leak testing or operating refrigerant compressors. Pressurized mixtures of air or gases containing oxygen can lead to an explosion.


CAUTION

EQUIPMENT DAMAGE HAZARD

Failure to follow this caution may result in equipment damage or improper operation.

Do not bury more than 36 in. (914 mm) of refrigerant pipe in the ground. If any section of pipe is buried, there must be a 6 in. (152 mm) vertical rise to the valve connections on the outdoor units. If more than the recommended length is buried, refrigerant may migrate to the cooler buried section during extended periods of system shutdown. This causes refrigerant slugging and could possibly damage the compressor at start-up.



INTRODUCTION

This service manual provides the necessary information to service, repair, and maintain the indoor units. This manual has an appendix with data required to perform troubleshooting. Use the Table of Contents to locate a desired topic.

MODEL NUMBER NOMENCLATURE

Table 1 —Unit Sizes

SYSTEMS TONS	VOLTAGE/PH/HZ	INDOOR MODEL
9	208-230/1/60	40MPHAQ09XA3
12		40MPHAQ12XA3
18		40MPHAQ18XA3
24		40MPHAQ24XA3



Use of the AHRI Certified TM Mark indicates a manufacturer's participation in the program. For verification of certification for individual products, go to www.ahridirectory.org.



SPECIFICATIONS

Table 2 — Specifications

SYSTEM	SIZE		9	12	18	24
	Indoor Model		40MPHAQ09XA3	40MPHAQ12XA3	40MPHAQ18XA3	40MPHAQ24XA3
ELECTRICAL	Voltage, Phase, Cycle	V/Ph/Hz	208/230-1-60	208/230-1-60	208/230-1-60	208/230-1-60
	Power Supply		Indoor unit powered from outdoor unit			
CONTROLS	MCA	A.	0.3	0.3	0.5	0.5
	Wireless Remote controller (°F/°C Convertible)		Standard	Standard	Standard	Standard
	Wired Remote controller (°F/°C Convertible)		Optional	Optional	Optional	Optional
OPERATING RANGE	Cooling Indoor DB Min - Max	°F (°C)	62~90 (17~32)	62~90 (17~32)	62~90 (17~32)	62~90 (17~32)
	Heating Indoor DB Min - Max	°F (°C)	32~86 (0~30)	32~86 (0~30)	32~86 (0~30)	32~86 (0~30)
PIPING	Pipe Connection Size - Liquid	in (mm)	1/4 (6.35)	1/4 (6.35)	3/8" (9.52)	3/8" (9.52)
	Pipe Connection Size - Suction	in (mm)	3/8 (9.52)	1/2 (12.7)	5/8" (15.9)	5/8" (15.9)
INDOOR COIL	Face Area (sq. ft.)	Sq. Ft.	2.2	2.2	3.9	3.9
	No. Rows		4	4	3	3
	Fins per inch		21	21	21	21
	Circuits		5	5	7	7
INDOOR	Unit Width	in (mm)	35.2 (895)	35.2 (895)	49.57 (1259)	49.57 (1259)
	Unit Height	in (mm)	11.7 (298)	11.7 (298)	14.25 (362)	14.25 (362)
	Unit Depth	in (mm)	9.8 (248)	9.8 (248)	11.10 (282)	11.10 (282)
	Net Weight	lbs (kg)	37.48 (17)	37.48 (17)	43.4 (19.7)	43.4 (19.7)
	Number of Fan Speeds		4	4	4	4
	Airflow (lowest to highest)	CFM	144/245/295/345	168/252/306/357	261/389/528/926	359/470/583/926
	Sound Pressure (lowest to highest)	dB(A)	29/35.5/41.5/45.6	29/35.5/41.5/46.8	35.1/40.8/46.1/55.9	36.1/43.3/46.4/56.5
	Air throw Data	ft (m)	21.98 (6.7)	22.97 (7)	28.80 (8.7)	31.66 (9.65)
	Moisture removal	Pint/h (L/h)	2.11 (1.0)	2.53 (1.2)	3.8 (1.8)	5.0 (2.39)
Field Drain Pipe Size O.D.	in (mm)	1 (25.4)	1 (25.4)	1 (25.4)	1 (25.4)	




*Performance may vary based on the compatible outdoor units. See respective pages for performance data.

DIMENSIONS

Sizes 9K and 12K

Table 3 — Dimension Sizes 09K and 12K

HIGH WALL UNIT SIZE		9K	12K
Voltage		(208/230V)	(208/230V)
Height	In. (mm)	11.7 (298)	11.7 (298)
Width	In. (mm)	35.2 (895)	35.2 (895)
Depth	In. (mm)	9.8 (248)	9.8 (248)
Weight-Net	Lbs (kg)	37.48 (17)	37.48 (17)



Drain Hose Ø0.625"(16) L=25.20"(640)

Units: Inch (mm)




Fig. 1 — Sizes 9K and 12K

NOTE: Drain adapter included with the indoor unit to allow the use of a 3/4 in. PVC Schedule 40 pipe where the actual outside diameter is 1.05 in.

Sizes 18K and 24K

Table 4 — Dimension Sizes 18K and 24K

HIGH WALL UNIT SIZE		18K	24K
Voltage		(208/230V)	(208/230V)
Height	In. (mm)	14.25 (362)	14.25 (362)
Width	In. (mm)	49.57 (1259)	49.57 (1259)
Depth	In. (mm)	11.10 (282)	11.10 (282)
Weight-Net	Lbs (kg)	43.4 (19.7)	43.4 (19.7)




Fig. 2 — Sizes 18K and 24K

CLEARANCES




Fig. 3 — Indoor Unit Clearances

NOTE: The top clearance recommended for proper return airflow is 5.9 in (15cm). Reduction of this clearance may decrease the performance of these units. This may be reduced to 3.2 in (80mm) as long as the right and left clearances are achieved.

ELECTRICAL DATA

Table 5 — Electrical Data

HIGH WALL UNIT SIZE		INDOOR FAN			MAX FUSE CB AMP
		V-Ph-Hz	FLA	HP	
Heat Pump Models	9K	208/230-1-60	0.34	0.027	Refer to outdoor unit installation instructions – Indoor unit powered by the outdoor unit
	12K		0.34	0.027	
	18K		0.5	0.082	
	24K		0.5	0.082	

WIRING

All wires must be sized per NEC (National Electrical Code) or CEC (Canadian Electrical Code) and local codes. Use the Electrical Data table MCA (minimum circuit amps) and MOCP (maximum over current protection) to correctly size the wires and the disconnect fuse or breakers respectively.

Per the caution note, only stranded copper conductors with a 600 volt insulation rating wire must be used.

Recommended Connection Method for Power and Communication Wiring:

The main power is supplied to the outdoor unit. The field supplied 14/3 stranded wire with ground with a 600 volt insulation rating, power/communication wiring from the outdoor unit to indoor unit consists of four (4) wires and provides the power for the indoor unit.

Two wires are line voltage AC power, one is communication wiring (S) and the other is a ground wire. Wiring between the indoor and outdoor unit is polarity sensitive. The use of BX wire is NOT recommended.

If installed in a high Electromagnetic field (EMF) area and communication issues exists, a 14/2 stranded shielded wire can be used to replace L2 and (S) between the outdoor unit and indoor unit landing the shield onto ground in the outdoor unit only.

CAUTION

EQUIPMENT DAMAGE HAZARD
Failure to follow this caution may result in equipment damage or improper operation.

Wires should be sized based on NEC and local codes.

CAUTION

EQUIPMENT DAMAGE HAZARD
Failure to follow this caution may result in equipment damage or improper operation.

Be sure to comply with local codes while running wire from the indoor unit to the outdoor unit.

Every wire must be connected firmly. Loose wiring may cause the terminal to overheat or result in unit malfunction. A fire hazard may also exist. Ensure all wiring is tightly connected.

No wire should touch the refrigerant tubing, compressor or any moving parts.

Disconnecting means must be provided and shall be located within sight and readily accessible from the air conditioner. Connecting cable with conduit shall be routed through the hole in the conduit panel.

CONNECTION DIAGRAM




Fig. 4 — 208-230V

NOTES:

1. Do not use thermostat wire for any connection between the indoor and outdoor units.
2. All connections between the indoor and outdoor units must be as shown in Figure 4. The connections are polarity sensitive and **improper wiring will result in a fault code.**

WIRING DIAGRAM

Sizes 09K to 12K

Indoor Wiring Diagram




Fig. 5 — Wiring Diagram - Sizes 09K and 12K

CODE	PART NAME
MAIN BOARD	
CN 10	Display board port DC 12V
CN 6	Output DC 5V pipe sensor
CN 8	Output DC-12V,Swing motor
CN 20	Output DC12V,Swing motor
CN 3	Output DC 310V,fan motor
P1_1	Earth Ground
L-IN	Power Voltage: AC 208-230V
N-IN	Power Voltage: AC 208-230V
CN 5	Output: DC 0-24V Communication port to outdoor
CN 32	Output: DC 12V function board
DISPLAY BOARD	
CN1	Input: DC 12V 4 wires connect to main board 3 wires connect to multi-function control board
CN 3	Output: DC 5V WI-FI controller (optional)
CN 2	Output: DC 5V Wire controller (optional)
CN 6	Output: DC 3.3V Infrared sensor (optional)
CN 5	Output: DC 5V Humidity sensor
CN 4	Output: DC5V Room temperature sensor (optional)
MULTI-FUNCTION CONTROL BOARD	
CN42 & CN41	Output: DC 5V To CCM Comm.Bus or 485 Wire-controller
CN 40	Input: DC 5V Connect to display board
CN 43	Input: DC 12V Connect to main board
CN 46	Output: DC 5V To Remote Switch

Sizes 18K to 24K




Fig. 6 — Wiring Diagram - Sizes 18K and 24K

CODE	PART NAME
MAIN BOARD	
S (Cn16)	Output:0-24VDC Communication port to outdoor
N(CN11)	Input:230VAC High Voltage N line from outdoor
L-IN (CN2)	Input:230VAC High Voltage L line from outdoor
CN 6	Output:230VAC High Voltage Heater port (optional)
CN 12	Output:230V High Voltage Ion port (optional)
CN 4	Output:310VDC High Voltage Indoor DC fan
P_1	Output:0V Ground line welding on PCB
CN 5	Output:12VDC Swing motor 1
CN 14	Output:12VDC Swing motor2 (optional)
CN 43	Output:0-5VDC Micro switch (optional)
CN 44	Output:12VDC Plasma port (optional)
CN 8	Output:12VDC Room temperature sensor (optional)
CN 9	Output:12VDC Pipe temperature sensor
CN10A(CN10)	Output:5VDC Connect to display board
DISPLAY BOARD	
CN 1	Input:5VDC 4 wires connect to main board 3 wires connect to multi-function control board
CN 3	Output:5VDC Wi-Fi controller (optional)
CN 2	Output:5VDC Wire controller (optional)
CN 6	Output:3.3VDC Infrared sensor (operational)
CN 5	Output:5VDC Humidity sensor
CN 4	Output:12VDC Room temperature sensor (optional)
MULTI-FUNCTION CONTROL BOARD	
CN42&CN41	Output:5VDC To CCM Comm. Bus or 485 Wire-controller
CN40	Input:5VDC Connect to display board
CN 46	Output:5VDC To Remote Switch

FAN AND MOTOR SPECIFICATIONS

Table 6 — Fan and Motor Specifications

HIGH WALL UNIT SIZE			9K	12K	18K	24K
			(208/230V)	(208/230V)	(208/230V)	(208/230V)
HIGH WALL FAN	Material		glass fiber+AS	glass fiber+AS	glass fiber+AS	glass fiber+AS
	Type		GL-108*670-IN	GL-108*670-IN	GL-118*955-I	GL-118*955-I
	Diameter	In (mm)	4.25 (108)	4.25 (108)	4.65 (118)	4.65 (118)
	Height	In (mm)	26.38 (670)	26.38 (670)	37.6 (955)	37.6 (955)
HIGH WALL FAN MOTOR	Model		ZKFP-20-8-6-7	ZKFP-20-8-6-7	ZKFP-58-8-1-5	ZKFP-58-8-1-5
	Volts	V	208/230	208/230	208/230	208/230
	Phase		1	1	1	1
	Hertz		60	60	60	60
	FLA		0.034	0.034	0.5	0.5
	Type		DC	DC	DC	DC
	Insulation class		E	E	E	E
	Safe class		IPX0	IPX0	IP40	IP40
	Input	W	50	50	58	58
	Output	W	20	20	60	60
	Range of current	Amps	0.023	0.023	0.1~0.48	0.1~0.48
	Rated current	Amps	0.023±10%	0.023±10%	0.65	0.65
	Capacitor	μF	No Capacitor			
	Rated HP	HP	0.027	0.027	0.082	0.082
	Speed	rev/min	1000/850/650	1050/900/650	1700/1660/1350	1700/1660/1350
	Rated RPM	rev/min	1000	1050	1700	1700
Max. input	W	70	70	125	125	

REFRIGERATION CYCLE DIAGRAM




Fig. 7 — Heat Pumps

REFRIGERANT LINES

IMPORTANT: Both refrigerant lines must be insulated separately.

Table 2 on page 3 lists the pipe sizes for the indoor unit. Refer to the outdoor unit installation instructions for other allowed piping lengths and refrigerant information.

SYSTEM EVACUATION AND CHARGING

⚠ **CAUTION**

UNIT DAMAGE HAZARD
 Failure to follow this caution may result in equipment damage or improper operation.

Never use the system compressor as a vacuum pump.

Refrigerant tubes and indoor coil should be evacuated using the recommended deep vacuum method of 500 microns. The alternate triple evacuation method may be used if the following procedure is followed. Always break a vacuum with dry nitrogen.

System Vacuum and Charge

Using Vacuum Pump

1. Completely tighten flare nuts on the line set at both the indoor and outdoor units. **DO NOT** open the service valves on the outdoor unit for the new installation or the replacement unit. Open the service valves on the outdoor unit if repairs have been made to the refrigerant sealed system. Connect the manifold gauge low pressure hose to the charge port of the gas side service valve (see Fig. 8).
2. Connect the charge hose to the vacuum pump.
3. Fully open the low pressure valve of manifold gage (see Fig. 9).
4. Start the vacuum pump.
5. Evacuate using deep vacuum or triple evacuation method.
6. After evacuation is complete, fully close the pressure valve side of manifold gage and stop the vacuum pump operation.
7. The factory charge contained in the outdoor unit is good for up to 25ft. (8 m) of line length. If vacuum is complete per Fig. 10 or 11, open service valves to release factory charge into the system.
8. Disconnect the charge hose from the charge connection of the gas side service valve.
9. Securely tighten the service valve caps.




Fig. 8 — Service Valve




Fig. 9 — Manifold

Deep Vacuum Method

The deep vacuum method requires a vacuum pump capable of pulling a vacuum of 500 microns and a vacuum gage capable of accurately measuring this vacuum depth. The deep vacuum method is the most positive way of assuring a system is free of air and liquid water (see Fig. 10).




Fig. 10 — Deep Vacuum Graph

Triple Vacuum Method

The triple evacuation method should be used. Refer to Fig. 9 and proceed as follows:

1. Pump the system down to 1500 microns and allow the pump to continue operating for an additional 15 minutes.
2. Close the service valves and shut off the vacuum pump.
3. Connect a dry nitrogen cylinder and regulator to the system and break vacuum until the system reaches 2 psig.
4. Close the service valve and allow the system to stand for 1hr. During this time, the dry nitrogen can diffuse throughout the system absorbing moisture.
5. Pump the system down to 1000 microns.
6. Break the vacuum with dry nitrogen (2 psig).
7. Pump the system down to 500 microns.
8. Perform the hold test for 30 minutes.




Fig. 11 — Triple Evacuation Method

Final Tubing Check

IMPORTANT: Check to be certain factory tubing on both indoor and outdoor unit has not shifted during shipment. Ensure tubes are not rubbing against each other or any sheet metal. Pay close attention to feeder tubes, making sure wire ties on feeder tubes are secure and tight.

OPERATION MODES AND FUNCTIONS

Abbreviation

Table 7 — Unit Element Abbreviations

ABBREVIATION	ELEMENT
T1	Indoor room temperature
T2	Evaporator Coil temperature
T3	Condenser Coil temperature
T4	Outdoor ambient temperature
Tsc	Adjusted setting temperature
TP	Compressor discharge temperature

Safety Features

Compressor Three-Minute Delay at Restart

Compressor functions are delayed for up to ten seconds upon the first start-up of the unit, and are delayed for up to three minutes upon subsequent unit restarts.

Automatic shutoff based on discharge temperature

If the compressor discharge temperature exceeds 226°F (108°C) for nine seconds, the compressor ceases operation.

Automatic shutoff based on fan speed

If the indoor fan speed registers below 300RPM or over 1500RPM for an extended period of time, the unit ceases operation and the corresponding error code is displayed on the indoor unit.

Inverter module protection

The inverter module has an automatic shutoff mechanism based on the unit's current, voltage, and temperature. If automatic shutoff is initiated, the corresponding error code is displayed on the indoor unit and the unit ceases operation.

Indoor fan delayed operation

- When the unit starts, the louver is automatically activated and the indoor fan will operate after a period of setting time or when the louver is in place.
- If the unit is in **HEATING** mode, the indoor fan is regulated by the anti-cold wind function.

Compressor Preheating

Preheating is automatically activated when the T4 sensor is lower than setting temperature.

Sensor redundancy and automatic shutoff

- If one temperature sensor malfunctions, the air conditioner continues operation and displays the corresponding error code, allowing for emergency use.
- When more than one temperature sensor malfunctions, the air conditioner ceases operation.

Display Function

Unit Display Functions



Fig. 12 — Unit Display Functions

Table 8 — Unit Function Displays

FUNCTION	DISPLAY
Temperature	Set temperature value
Temperature (FAN and DRYING mode)	Room temperature
Activation of Timer ON, Fresh, Swing, Turbo, or Silent	ON (3S)
Cancellation of Timer OFF, Fresh, Swing, Turbo, or Silent	OF (3S)
Defrost	dF
Warming in heating mode	cF
Self-clean	SC
Heating in room temperature under 46°F (8°C) or 54°F (12°C)	FP
Fresh (Not available on these systems)	
ECO function	eco
Wi-Fi Control	
The current operation power (Not available on these systems)	kW

FAN Mode

When the FAN mode is activated:

- The outdoor fan and compressor stop.
- Temperature control is disabled and the indoor room temperature is displayed.
- The indoor fan speed can be set to 1%~100%, or **AUTO**.
- The louver operations are identical to those in **COOLING** mode.
- Auto fan: In **FAN-ONLY** mode, the AC operates the same as auto fan in the **COOLING** mode with the temperature set at 75°F (24°C). (Tsc=75°F (24°C)).

COOLING Mode

Compressor control

Reach the configured temperature:

1. When the compressor runs continuously for less than 120 minutes.
 - If the following conditions are satisfied, the compressor ceases operation.
 - While the calculated frequency (fb) is less than the minimum limit frequency (FminC).
 - While protective time is more than or equal to ten minutes.
 - While T1 is lower than or equal to (Tsc-CDIFTEMP -1°F (-0.5°C))

NOTE: CDIFTEMP is the EEPROM setting parameter. It is 4°F (2°C).

2. When the compressor runs continuously for more than 120 minutes.
 - If the following conditions are satisfied, the compressor ceases operation.
 - When calculated frequency (fb) is less than minimum limit frequency (FminC).
 - When protective time is more than or equal to ten minutes.
 - When T1 is lower than or equal to (Tsc-CDIFTEMP).

NOTE: CDIFTEMP is the EEPROM setting parameter. It is 4°F (2°C).

3. If one of the following conditions is satisfied, regardless of time.
 - Compressor running frequency is more than the test frequency.
 - When the compressor running frequency is equal to the test frequency, T4 is more than 59°F (15°C) or no T4 or T4 fault.
 - Change setting temperature
 - Turbo or sleep function on/off
 - Various frequency limit shutdown occurs

NOTE: CDIFTEMP is EEPROM setting parameter. It is 4°F (2°C).

Indoor Fan Control

1. In the **COOLING** mode, the indoor fan operates continuously. The fan speed can be set to 1%-100%, or **AUTO**.
2. **AUTO** fan
 - **Descent Curve**
 - When T1-Tsc is lower than or equal to 6°F (3.5°C), fan speed reduces to 80%;
 - When T1-Tsc is lower than or equal to 2°F (1°C), fan speed reduces to 60%;
 - When T1-Tsc is lower than or equal to 1°F (0.5°C), fan speed reduces to 40%;
 - When T1-Tsc is lower than or equal to 0°F (0°C), fan speed reduces to 20%;
 - When T1-Tsc is lower than or equal to -1°F (-0.5°C), fan speed reduces to 1%.
 - **Rise Curve**
 - When T1-Tsc is higher than 0°F (0°C), fan speed increases to 20%;
 - When T1-Tsc is higher than 1°F (0.5°C), fan speed increases to 40%;
 - When T1-Tsc is higher than 2°F (1°C), fan speed increases to 60%;
 - When T1-Tsc is higher than 3°F (1.5°C), fan speed increases to 80%;
 - When T1-Tsc is higher than 7°F (4°C), fan speed increases to 100%.

Outdoor Fan Control

- The outdoor unit runs at a different fan speed according to T4 and the compressor running frequency.
- For different outdoor units, the fan speeds are different.

Condenser Temperature Protection

When the condenser temperature exceeds a configured value, the compressor ceases operations.

Evaporator Temperature Protection

When the evaporator temperature drops below a configured value, the compressor and outdoor fan ceases operations.

HEATING Mode

Compressor control

1. Reach the configured temperature:
 - If the following conditions are satisfied, the compressor ceases operation.
 - While the calculated frequency (fb) is less than the minimum limit frequency (FminC).
 - When the protective time is more than or equal to ten minutes.
 - When T1 is higher than or equal to Tsc+HDIFTEMP2.

NOTE: HDIFTEMP2 is the EEPROM setting parameter. It is 4°F (2°C).

- If one of the following conditions is satisfied, regardless of time.
 - Compressor running frequency is more than test frequency.
 - When the compressor running frequency is equal to the test frequency, T4 is more than 59°F (15°C) or no T4 or T4 fault.
 - Change the setting temperature.
 - **TURBO** or **SLEEP** function on or off.
2. When the current is higher than the predefined safe value, the surge protection is activated, causing the compressor to cease operations.

Indoor Fan Control

1. In the **HEATING** mode, the indoor fan operates continuously. The fan speed can be set to 1%-100%, or muted.
2. **AUTO** fan
 - **Rise curve**
 - When T1-Tsc is higher than -3°F (-1.5°C), fan speed reduces to 80%;
 - When T1-Tsc is higher than 0°F (0°C), fan speed reduces to 60%;
 - When T1-Tsc is higher than 1°F (0.5°C), fan speed reduces to 40%;
 - When T1-Tsc is higher than 2°F (1°C), fan speed reduces to 20%.
 - **Descent curve**
 - When T1-Tsc is lower than or equal to 1°F (0.5°C), fan speed increases to 20%;
 - When T1-Tsc is lower than or equal to 0°F (0°C), fan speed increases to 60%;
 - When T1-Tsc is lower than or equal to -3°F (-1.5°C), fan speed increases to 80%;
 - When T1-Tsc is lower than or equal to -1.5°F (-3°C), fan speed increases to 100%.

Outdoor Fan Control

- The outdoor unit runs at a different fan speed according to T4 and compressor running frequency.
- For different outdoor units, the fan speeds differ.

DEFROSTING Mode

- The unit enters defrosting mode according to changes in the temperature value of T3, T4 as well as the compressor running time.
- In the **DEFROSTING** mode, the compressor continues to run, the indoor and outdoor motor will cease operation, the defrost light of the indoor unit will turn on, and the „**df**“ symbol appears.
- If any one of the following conditions is satisfied, defrosting ends and the machine switches to the normal **HEATING** mode:
 - T3 rises above TCDE1C.
 - T3 maintained above TCDE2C for 80 seconds.
 - Unit runs for 15 minutes consecutively in the **DEFROSTING** mode.

Evaporator Temperature Protection

- **Off:** Compressor stops.
- **Decrease:** Decrease the running frequency to the lower level per 20 seconds.
- **Hold:** Keep the current frequency.
- **Resume:** No limitation for frequency.

AUTO Mode

- This mode can be selected with the remote controller and the setting temperature can be changed between 61°F~86°F (16°C~30°C).
- In the **AUTO** mode, the machine selects the **COOLING**, **HEATING**, **AUTO-DRYING** or **FAN-ONLY** mode on the basis of T1, Ts, T4 and relative humidity.
- If the setting temperature is modified, the machine selects a new running function.

DRY Mode

In the **DRY** mode, the air conditioner operates the same as auto fan in the **COOLING** mode.

1. Mute function is active.
 - All protections are activated and operate the same as they do that in **COOLING** mode.
2. Low Room Temperature Protection
 - If the room temperature is lower than 50°F (10°C), the compressor ceases operations and does not resume until the room temperature exceeds 54°F (12°C).

Forced Operation Function

- Forced **COOLING** Mode
The compressor and outdoor fan continues to run and the indoor fan runs at rated speed. After running for 30 minutes, the air conditioner switches to **AUTO** mode with a preset temperature of 75°F (24°C).
- Forced **AUTO** Mode:
Forced auto mode operates the same as normal **AUTO** mode with a preset temperature of 75°F (24°C).
- The unit exits the forced operation when it receives the following signals:
 - Switch on
 - Switch off
 - Timer on
 - Timer off
 - Changes in:
 - Mode
 - Fan Speed
 - Setting Temperature

Timer Function

- The Timing range is 24 hours.
- Timer on. The machine turns on automatically when reaching the setting time.
- Timer off. The machine turns off automatically when reaching the setting time.
- Timer on/off. The machine turns on automatically when reaching the setting “on” time, and then turns off automatically when reaching the setting “off” time.
- Timer off/on. The machine turns off automatically when reaching the setting “off” time, and then turns on automatically when reaching the setting “on” time.
- The timer function will not change the AC current operation mode. Suppose the AC is off now, it will not start up first after setting the “timer off” function. And when reaching the setting time, the timer **LED** will be off and the AC running mode has not been changed.
- The setting time is relative time.
- The AC will quit the timer function when it has malfunction.

SLEEP Function

- The **SLEEP** function is available in **COOLING**, **HEATING**, or **AUTO** modes.
- The operational process for sleep mode is as follows:
 - When cooling, the temperature rises 2°F (1°C) (to not higher than 86°F (30°C)) every hour. After 2 hours, the temperature stops rising and the indoor fan is fixed at low speed.
 - When heating, the temperature decreases 2°F (1°C) (to not lower than 61°F (16°C)) every hour.
 - After 2 hours, the temperature stops decreasing and the indoor fan is fixed at low speed. Anti-cold wind function takes priority.
- The operating time for the **SLEEP** mode is 8 hours, after which, the unit exits this mode and turns off.
- The timer setting is available in this mode.

Auto-Restart Function

- The indoor unit has an auto-restart module that allows the unit to restart automatically. The module automatically stores the current settings and, in the case of a sudden power failure, will restore those settings automatically within 3 minutes after power returns.
- If there is a power failure while the unit is running, the compressor starts 3 minutes after the unit restarts. If the unit was already off before the power failure, the unit stands by.

46°F (8°C) Heating

In the **HEATING** mode, the temperature can be set to as low as 46°F (8°C), preventing the indoor area from freezing if unoccupied during severe cold weather.

ECO Function

- Used to enter the energy efficient mode.
 - Under the **COOLING** mode, press **ECO**, the remote controller adjusts the temperature automatically to 75°F (24°C), **AUTO** fan speed to save energy (however only if the set temperature is less than 75°F (24°C)). If the set temperature is more than 75°F (24°C) and 86°F (30°C), press **ECO**, the fan speed will change to **AUTO**, the set temperature will remain unchanged.
- When AC receives signals, such as switch off, **Turbo** operation, **Silence** operation, **Self Clean** operation, Forced **COOLING** operation, mode setting, **SLEEPING** mode, or adjusting the set temperature to less than 75°F (24°C), it will exit the **ECO** operation.
- Operation time in **ECO** mode is 8 hours. After 8 hours the air conditioner exits this mode.
- If there is a malfunctioning temperature sensor in, the air conditioner will exit **ECO** mode.
- The indoor fan runs at auto fan when it enters the **ECO** mode. The setting temperature and setting fan speed can be changed with the remote controller.

Self Clean

- Press “**Self Clean**” when the unit is in the **COOLING** or **DRYING** mode, the indoor unit runs at the low fan speed for 16 minutes then turn off.
- **Self Clean** keeps the indoor unit dry and prevents mold growth.

Follow Me

- If you press “**Follow Me**” on the remote controller, the indoor unit will beep. This indicates the “**Follow Me**” function is active.
- Once active, the remote controller will send a signal every 3 minutes, with no beeps. The unit automatically sets the temperature according to the measurements from the remote controller.
- The unit will only change modes if the information from the remote controller makes it necessary, not from the unit’s temperature setting.
- If the unit does not receive a signal for 7 minutes or you press “**Follow Me**”, the function turns off. The unit regulates temperature based on its own sensor and settings.

Silence

Press **SILENCE** on the remote controller to enable the **SILENCE** function. While this function is active, the indoor unit runs at faint breeze (1% fan speed), which reduces noise to the lowest possible level.

Occupancy Sensor (Sizes 09K-12K)

With the built-in infrared sensor, the indoor unit detects human movement. The compressor operates in a low frequency if you leave the room for 30 minutes. The compressor operates in a lower frequency if you leave the room for 120 minutes, and resumes automatically when you come back, which helps save energy.

Information Inquiry

To enter information inquiry status, complete the following procedure within ten seconds:

- Press **LED** 3 times.
- Press **SWING** up-down 3 times. If successful, you will hear beeps for two seconds.
- Use **LED** and **SWING** up-down to cycle through the information displayed.
- Press **LED** to display the next code in the sequence.
- Press **SWING** up-down to display the previous code.

Table 9 displays the information codes. The screen displays the code for two seconds, then the information for 25 seconds.

Table 9 — Information Codes

DISPLAYED CODE	EXPLANATION	ADDITIONAL NOTES
T1	T1	T1 temperature
T2	T2	T2 temperature
T3	T3	T3 temperature
T4	T4	T4 temperature
TP	TP	TP temperature
Targeted Frequency	FT	Targeted Frequency
Actual Frequency	TR	Actual Frequency
Compressor Current	dL	N/A
Outdoor AC Voltage	UO	N/A
Indoor capacity test	Sn	N/A
Reserve	--	Running mode
Outdoor Fan Speed	Pr	Outdoor fan speed
EXV opening angle	LR	EXV opening angle
Indoor fan speed	IR	Indoor fan speed
Indoor humidity	HU	N/A
Adjusted setting temperature	TT	N/A
Indoor dust concentrations	DT	N/A - Not available
WIFI signal strength	IF	N/A
GA algorithm frequency	OT	N/A

TROUBLESHOOTING

Safety




Fig. 13 — Electrolytic Capacitors

For other models, please connect discharge resistance (approximately 100Ω 40W) or a soldering iron (plug) between the +, - terminals of the electrolytic capacitor on the other side of the outdoor PCB.




Fig. 14 — Discharge Position

NOTE: Fig. 14 is for reference only. Actual appearances may vary.

TROUBLESHOOTING (continued)

Error Display (Indoor Unit)

When the indoor unit encounters a recognized error, the indicator light flashes in a corresponding series, the timer display may turn on or begin flashing, and an error code displays. These error codes are described in Table 10.

Table 10 — Error Codes

DISPLAY	ERROR INFORMATION	SOLUTION
E0/EA	Indoor unit EEPROM parameter error	Page 27
E1	Indoor / outdoor units communication error	Pages 28 - 29
E2	Zero crossing detection error diagnosis and solution	Page 30
E3	The indoor fan speed is operating outside of the normal range	Page 31
E4	Indoor room temperature sensor T1 is in open circuit or has short circuited	Page 37
E5	Evaporator coil temperature sensor T2 is in open circuit or has short circuited	Page 37
EB	Communication error between the indoor PCB and display board	Page 38
EF	Occupancy Sensor module error	Page 33
F0	Overload current protection	Page 39
F1	Outdoor ambient temperature sensor T4 open circuit or short circuit	Page 37
F2	Condenser coil temperature sensor T3 is in open circuit or has short circuited	Page 37
F3	Compressor discharge temperature sensor TP open circuit or short circuit	Page 37
F4	Outdoor unit EEPROM parameter error	Page 27
F5	The outdoor fan speed is operating outside of the normal range	Page 31
P0	IPM malfunction or IGBT over-strong current protection	Page 40
P1	Over voltage or over low voltage protection	Page 34
P2	High temperature protection of IPM module	Page 35
P3	Outdoor ambient temperature is too low	
P4	Inverter compressor drive error	Page 36

For other codes

The display board may show a garbled code or a code undefined by the service manual. Ensure that this code is not a temperature reading.

Troubleshooting

Test the indoor unit using the remote control. If the unit display is working however will not respond to the remote, the indoor PCB needs to be replaced. If there is no display after pressing **LED** and the unit responds, the display board needs to be replaced.

ERROR DIAGNOSIS AND TROUBLESHOOTING WITHOUT ERROR CODE


WARNING

UNIT DAMAGE HAZARD

Be sure to turn off unit before any maintenance to prevent damage or injury.

Table 11 — Remote Maintenance

Remote Maintenance	Electrical Circuit							Refrigerant Circuit							Others					
	Power failure	The main power tripped	Loose connections	Faulty transformer	The voltage is too high or too low	The remote control is powered off	Broken remote control	Dirty air filter	Dirty condenser fins	The setting temp is higher/lower than the room's (cooling/heating)	The ambient temp. is too high/low when the mode is cooling/heating	Fan mode	SILENCE function is activated (optional function)	Frosting and defrosting frequently	Heavy load condition	Loose hold down bolts and/or screws	Not air tight	Air inlet or outlet of either unit is blocked	Interference from cell phones towers and remote boosters	Shipping plates remained attached
Unit will not start	☆	☆	☆	☆																
Operation is erratic, unpredictable or unit is unresponsive																			☆	
Cannot set desired temp.						☆	☆													
Unit is on but the wind is not cold (hot)									☆	☆	☆									
Unit runs, but shortly stops					☆				☆	☆										
The unit starts up and stops often					☆					☆			☆					☆		
Unit runs continuously however insufficient cooling (heating)								☆	☆	☆	☆	☆		☆			☆	☆		
Cool can not change to heat																				
Unit is noisy																☆				☆
Unit emits bad odor								☆												
Test method/ remedy	Test voltage	Close the power switch	Inspect connections - tighten	Change the transformer	Test voltage	Replace the battery of the remote control	Replace remote control	Clean or replace	Clean	Adjust the setting temp.	Turn the AC later	Adjust to Cool mode	Turn off SILENCE function.	Turn the AC later	Check the heat load	Tighten bolts or screws	Close all windows and doors	Remove the obstacles	Reconnect the power or press ON/OFF button on remote control to restart	Remove them

ERROR DIAGNOSIS AND TROUBLESHOOTING WITHOUT ERROR CODE (continued)

Table 12 — Field Maintenance

Field Maintenance	Electrical Circuit														
	Power failure	Blown fuse or varistor	Loose connections	Shorted or broken wires	Safety device opens	Faulty thermostat/ room temp sensor	Wrong setting place of temp sensor	Faulty transformer	Shorted or open capacitor	Faulty magnetic contact for compressor	Faulty magnetic contact for fan	Low voltage	Faulty stepping motor	Shorted or grounded compressor	Shorted or grounded fan motor
Unit will not start	☆	☆	☆	☆	☆			☆							
Compressor will not start however the fan runs				☆		☆			☆	☆				☆	
Compressor and condenser (outdoor) fan will not start				☆		☆				☆					
Evaporator (indoor) fan will not start				☆					☆		☆				☆
Condenser (outdoor) fan will not start				☆		☆			☆		☆				☆
Unit runs but shortly stops										☆		☆			
Compress or short cycles due to overload										☆		☆			
High discharge pressure															
Low discharge pressure															
High suction pressure															
Low suction pressure															
Unit runs continuously but insufficient cooling															
Too cool						☆	☆								
Compressor is noisy															
Horizontal louver can not revolve			☆	☆									☆		
Test method / remedy	Test voltage	Inspect fuse type & size	Inspect connections - tighten	Test circuits with tester	Test continuity of safety device	Test continuity of thermostat / sensor & wiring	Place the temp. sensor at the central of air in- let grille	Check control circuit with tester	Check capacitor with tester	Test continuity of coil & contacts	Test continuity of coil & contacts	Test voltage	Replace the stepping motor	Check resistance with Megger tester	Check resistance with Megger tester

ERROR DIAGNOSIS AND TROUBLESHOOTING WITHOUT ERROR CODE (continued)

Table 13 — Field Maintenance

Field Maintenance	Refrigerant Circuit																		
	Compressor stuck	Refrigerant Shortage	Restricted liquid line	Dry air filter	Dirty evaporator coil	Insufficient air through evaporator coil	Refrigerant overcharge	Dirty or partially blocked condenser	Air or non-condensable gas in refrigerant cycle	Short cycling of condensing air	High temp. condensing medium	Insufficient condensing medium	Broken compressor internal parts	Insufficient compressor	Expansion valve obstructed	Expansion valve or capillary tube closed completely	Leaking power element on expansion valve	Power installation of feeler bulb	
Unit will not start																			
Compressor will not start however the fan runs	☆																		
Compressor and condenser (outdoor) fan will not start																			
Evaporator (indoor) fan will not start																			
Condenser (outdoor) fan will not start																			
Unit runs but shortly stops		☆	☆				☆	☆								☆	☆		
Compress or short cycles due to overload		☆					☆	☆											
High discharge pressure							☆	☆	☆	☆	☆	☆							
Low discharge pressure		☆												☆					
High suction pressure							☆							☆					☆
Low suction pressure		☆	☆	☆	☆	☆									☆	☆	☆		
Unit runs continuously but insufficient cooling		☆	☆	☆	☆	☆		☆	☆	☆				☆					
Too cool																			
Compressor is noisy							☆						☆						
Horizontal louver can not revolve																			
Test method / remedy	Replace the compressor	Leak test	Replace the restricted part	Clean or replace	Clean coil	Check fan	Change charged refrigerant volume	Clean condenser or remove obstacle	Purge, evacuate and recharge	Remove obstruction to air flow	Remove obstruction in air or water flow	Remove obstruction in air or water flow	Replace compressor	Test compressor efficiency	Replace valve	Replace valve	Replace valve	Fix feeler bulb	

ERROR DIAGNOSIS AND TROUBLESHOOTING WITHOUT ERROR CODE (continued)

Table 14 — Field Maintenance

Field Maintenance	Others				
Possible causes of trouble	Heavy load condition	Loosen hold down bolts and/or screws	Shipping plates remain attached	Poor choices of capacity	Contact of piping with other piping or external plate
Unit will not start					
Compressor will not start however the fan runs					
Compressor and condenser (outdoor) fan will not start					
Evaporator (indoor) fan will not start					
Condenser (outdoor) fan will not start					
Unit runs but shortly stops					
Compress or short cycles due to overload					
High discharge pressure					
Low discharge pressure					
High suction pressure	☆				
Low suction pressure					
Unit runs continuously but insufficient cooling	☆			☆	
Too cool					
Compressor is noisy		☆	☆		☆
Horizontal louver can not revolve					
Test method / remedy	Check heat load	Tighten bolts or screws	Remove them	Choose AC of larger capacity or add the number of units	Fix piping as not to touch each other or external pipe

QUICK MAINTENANCE BY ERROR CODE

If you do not have the time to test whether specific parts are faulty, you can directly change the required parts according the error code. You can find the parts to replace by error code in Tables 15 and 16.

Table 15 — Error Codes

Part Requiring Replacement	ERROR CODE									
	E0	EA	E1	E2	E3	E4	E5	EB	EF	F0
Indoor PCB	√	√	√	√	√	√	√	√	x	x
Outdoor PCB	x	x	√	x	x	x	x	x	x	√
Display Board	x	x	x	x	x	x	x		x	x
Reactor	x	x	√	x	x	x	x	x	x	x
Indoor fan motor	x	x	x	x	√	x	x	x	x	x
Outdoor fan motor	x	x	x	x	X	x	x	x	x	x
Temperature sensor	x	x	x	x	x	√	√	x	x	x
T2 Sensor	x	x	x	x	x	x	x	x	x	x
Additional refrigerant	x	x	x	x	x	x	x	x	x	x
Compressor	x	x	x	x	x	x	x	x	x	√
IPM board	x	x	x	x	x	x	x	x	x	x
Outdoor unit	x	x	x	x	x	x	x	x	x	√
Occupancy Sensor (Only Sizes 09-12)	x	x	x	x	x	x	x	x	√	x

Table 16 — Error Codes

Part Requiring Replacement	Error Code									
	F1	F2	F3	F4	F5	P0	P1	P2	P4	
Indoor PCB	x	x	x	x	x	x	x	x	x	
Outdoor PCB	√	√	√	√	√	√	√	√	√	
Display Board	x	x	x	x	x	x	x	x	x	
Reactor	x	x	x	x	x	x	√	x	x	
Indoor fan motor	x	x	x	x	x	x	x	x	x	
Outdoor fan motor	x	x	x	x	√	x	x	x	x	
Temperature sensor	√	√	√	x	x	x	X	x	x	
T2 Sensor	x	x	x	x	x	x	x	x	x	
Additional refrigerant	x	x	x	x	x	x	x	x	x	
Compressor	x	x	x	x	x	√	x	x	√	
IPM board	x	x	x	x	x	√	√	x	√	
Outdoor unit	x	x	x	x	x	x	x	x	x	
Occupancy Sensor	x	x	x	x	x	x	x	x	x	

TROUBLESHOOTING BY ERROR CODE

Common Check Procedures

Temperature Sensor Check

Disconnect the temperature sensor from PCB, measure the resistance value with a tester.

Temperature Sensors.

Room temp. (T1) sensor,

Indoor coil temp. (T2) sensor,

Outdoor coil temp.(T3) sensor,

Outdoor ambient temp.(T4) sensor,

Compressor discharge temp.(Tp) sensor.

Measure the resistance value of each winding by using the multi-meter.

Compressor Checking

Measure the resistance value of each winding by using the tester.




Fig. 15 — Compressor Checking

Table 17 — Compressor Checking

POSITION	RESISTANCE VALUE
	ATM115D43UFZ2
Blue - Red	1.87Ω(20°C/68°F)
Blue - Black	
Red - Blue	



IPM Continuity Check

Turn off the power. Allow the large capacity electrolytic capacitors to discharge completely, and dismantle the IPM. Use a digital tester to measure the resistance between P and UVWN; UVW and N.

Table 18 — IPM Continuity Check

Digital Tester		Normal Resistance Value	Digital Tester		Normal Resistance Value
(+) Red	(-) Black		(+) Red	(-) Black	
P	N	∞ (Several M Ω)	U	N	∞ (Several M Ω)
	U		V		
	V		W		
	W		(+) Red		

DIAGNOSIS AND SOLUTION


E0/F4/EA (EEPROM Parameter Error)

Description: Indoor or outdoor PCB main chip does not receive feedback from EEPROM chip.

Recommended parts to prepare:

- Indoor PCB
- Outdoor PCB
- Reactor

Troubleshooting and Repair:



Remarks:

The location of the EEPROM chip on the indoor and outdoor PCB is shown in Figures 16 and 17:




Fig. 16 —EEPROM Chip (Indoor Unit)




Fig. 17 —EEPROM Chip (Outdoor Unit)


E1 (Indoor and Outdoor Unit Communication Error)

Description: The indoor unit has not received feedback from the outdoor unit for 150 seconds, four consecutive times.

Recommended parts to prepare:

- Indoor PCB
- Outdoor PCB
- Reactor

Troubleshooting and Repair:



E1 (Indoor and Outdoor Unit Communication Error) (continued)

Remarks:

- Use a multimeter to test the DC voltage between the outdoor unit's 2 port and 3 port. The red pin of multimeter connects with the 2 port while the black pin is for 3 port.
- When the air conditioner is normal running, the voltage is moving alternately as positive values and negative values.
- If the outdoor unit has a malfunction, the voltage has always been the positive value.
- If the indoor unit has malfunction, the voltage is a fixed value.




Fig. 18 — Multimeter

- Use a multimeter to test the reactor resistance that does not connect with the capacitor.
- The normal value should be around zero ohm otherwise the reactor is malfunctioning.




Fig. 19 — Multimeter


E2 (Zero crossing detection error diagnosis and solution)

Description: When PCB does not receive zero crossing signal feedback for 4 minutes or the zero crossing signal time interval is abnormal.

Recommended parts to prepare:

- Connection wires
- PCB

Troubleshooting and repair:




E3/F5 (Fan speed is operating outside of the Normal Range)

Description: When the indoor fan speed maintains a low speed (ex. 300RPM) or a speed that's too high (ex.1500RPM) for a certain time, the unit stops and the LED displays the failure (E3). When the outdoor fan speed registers below 200RPM or over 1500RPM for an extended period of time, the unit stops and the LED displays the failure (F5).

Recommended parts to prepare:

- Wiring
- Faulty fan assembly
- Faulty fan motor
- Faulty PCB

Troubleshooting and Repair:



Index

1. Indoor or Outdoor DC Fan Motor (control chip is in the fan motor)

Power on and when the unit is in standby, measure the voltage of pin1-pin3, pin4-pin3 in the fan motor connector. If the value of the voltage is not in the range shown in Table 19, the PCB must has problems and need to be replaced.

DC motor voltage input and output (voltage: 220-240V~):

Table 19 — Voltage

NO.	COLOR	SIGNAL	VOLTAGE
1	Red	Vs/Vm	280V~380V
2	---	---	---
3	Black	GND	0V
4	White	Vcc	14-18.5V
5	Yellow	Vsp	0~5.6V
6	Blue	FG	14-18.5V




Fig. 20 — Indoor DC Fan Motor

2. Outdoor DC Fan Motor (control chip is in outdoor PCB)

Power on and check if the fan can run normally, if the fan can run normally, the PCB must have a problem and needs to be replaced, If the fan can not run normally, measure the resistance of each pin (two). If the resistance is not equal to each other, the fan motor must have a problem and needs to be replaced, otherwise the PCB must has problems and needs to be replaced.




Fig. 21 — Outdoor DC Fan Motor

3. Indoor AC Fan Motor

Power on and set the unit running in FAN mode at the high fan speed. After running for 15 seconds, measure the voltage of pin1 and pin2. If the value of the voltage is less than 100V(208~240V power supply) or 50V(115V power supply), the PCB must has problems and needs to be replaced.




Fig. 22 — Indoor AC Fan Motor


EF (Occupancy Sensor Module Error Diagnosis and Solution)

Description: If the Occupancy Sensor module malfunctions, the LED displays the failure.

Recommended parts to prepare:

- Occupancy Sensor

Troubleshooting and Repair:




P1 (Over voltage or too low voltage protection diagnosis and solution)

Description: Abnormal increases or decreases in voltage are detected by checking the specified voltage detection circuit.

Recommended parts to prepare:

- Power supply issues
- System leakage or blockage
- Faulty PCB

Troubleshooting and Repair:




P2 (High temperature protection of IPM module diagnosis and solution)

Description: If the temperature of IPM module is higher than limited value, the LED displays this failure code.

Recommended parts to prepare:

- Faulty PCB
- Connection problems

Troubleshooting and Repair:




P4 (Inverter compressor drive error diagnosis and solution)

Description: If the temperature of IPM module is higher than limited value, the LED displays this failure code.

Recommended parts to prepare:

- Wiring mistake
- PM malfunction
- Outdoor fan assembly faulty
- Compressor malfunction
- Outdoor PCB faulty

Troubleshooting and Repair:



E4/E5/F1/F2/F3 (Open circuit or short circuit of temperature sensor diagnosis and solution)

Description: If the sampling voltage is lower than 0.06V or higher than 4.94V, the LED displays the failure.

Recommended parts to prepare:

- Wiring mistake
- Faulty sensor
- Faulty PCB

Troubleshooting and Repair:





Fig. 23 —Multimeter


Eb (Communication error between the Indoor PCB and Display Board)

Description: Indoor PCB does not receive feedback from the display board.

Recommended parts to prepare:

- Wiring mistake
- PCB faulty
- Display board malfunction

Troubleshooting and Repair:




F0 (Overload current protection diagnosis and solution)

Description: An abnormal current rise is detected by checking the specified current detection circuit.

Recommended parts to prepare:

- Power supply problems
- System blockage
- Faulty PCB
- Wiring mistake
- Compressor malfunction

Troubleshooting and Repair:




P0 (IPM malfunction or IGBT over-strong current protection diagnosis and solution)

Description: When the voltage signal the IPM sends to the compressor drive chip is abnormal, the display LED displays “P0” and the air conditioner turns off.

Recommended parts to prepare:



- Wiring mistake
- IPM malfunction
- Faulty outdoor fan assembly
- Compressor malfunction
- Faulty outdoor PCB

Troubleshooting and Repair:





DISASSEMBLY INSTRUCTIONS




Indoor Unit Sizes 09K-12K (Front Panel)

Procedure	Illustration
<p>1) Hold the front panel by the tabs on both sides and lift it.</p>	 <p>The illustration shows a hand on the left and another hand on the right holding the front panel of the indoor unit. A dashed line indicates the panel being lifted upwards. A curved arrow points upwards from the center of the panel. A label 'Front Panel' points to the top edge of the panel, and a label 'Tab' points to a small protrusion on the bottom edge of the panel.</p>
<p>2) Push up the bottom of the air filter while pressing the bottom of the unit, and then pull the air filter out (downwards).</p>	 <p>The illustration shows the front panel removed and the air filter being pulled out. A hand is shown pushing up the bottom of the filter. A curved arrow points upwards from the center of the filter. A label 'Filter' points to the filter itself.</p>

Indoor Unit Sizes 09K-12K (Front Panel) (continued)



Procedure	Illustration
<p>3) Open the horizontal louver and push the hook towards the right to open.</p>	 <p>The illustration shows a side view of the indoor unit's front panel with the horizontal louver partially open. A dashed line points to the louver with the label "Horizontal Louver". A circular inset provides a magnified view of the hook mechanism. In this inset, a hand is shown pushing a hook to the right, as indicated by a black arrow. A dashed line points to the hook with the label "Hook".</p>
<p>4) Bend the horizontal louver lightly with both hands to loosen the hooks, then remove the horizontal louver.</p>	 <p>The illustration shows the same side view of the indoor unit's front panel. The horizontal louver is now bent downwards at its ends. A dashed line points to the hook mechanism with the label "Hook".</p>

Indoor Unit Sizes 09K-12K (Front Panel) (continued)



Procedure	Illustration
<p>5) Remove the screw (1) then remove the electrical cover.</p> <p>6) Disconnect the two connectors on the display board.</p>	
<p>7) Slide the front panel side to side to release each axis.</p>	
<p>8) Remove the screw (1) and rotate the display board clockwise. Next, remove the clips.</p>	

Indoor Unit Sizes 09K-12K (Electrical Parts) (Anti-static gloves must be worn)




NOTE: Remove the front panel (refer to the front panel removal steps) before disassembling electrical parts.

Procedure	Illustration
<ol style="list-style-type: none">1) Cut the ribbon with a shear, then pull out the coil temperature sensor (T2).2) Remove the screws (2) used for the ground connection.	 <p>The illustration shows a side view of the indoor unit's electrical compartment. A hand is using a screwdriver to remove a screw from the top of the unit, labeled 'Ground Screws'. A coil temperature sensor, labeled 'T2 Sensor', is being pulled out from the unit. A ribbon cable is also labeled 'Ribbon'.</p>
<ol style="list-style-type: none">3) Remove the screws (1 for the electronic cover and 1 for the terminal cover). Next, remove the electronic box cover and the terminal cover along the direction indicated in the image (on the right side) to remove it.4) Disconnect the fan motor connector and the step motor.	 <p>The illustration shows the same side view of the indoor unit's electrical compartment. An arrow points to the right, indicating the direction to remove the electronic box cover and the terminal cover.</p>



Indoor Unit Sizes 09K-12K (Electrical Parts) (Anti-static gloves must be worn) (continued)

Procedure	Illustration
<p>5) Disconnect the wires. Next, remove the electronic main box.</p> <p>6) Pull out the electrical control box along the direction indicated in the image to remove it.</p>	 <p>Main Board</p> <p>Electronic Box</p>
<p>7) Each port connector is indicated in the image to the right.</p>	 <p>Pipe Temperature Sensor</p> <p>Display Board</p> <p>Swing Motor</p> <p>Terminals</p> <p>Ground Wire</p> <p>Indoor Fan Motor</p>

Indoor Unit Sizes 09K-12K (Evaporator)



Procedure	Illustration
1) Disassemble the pipe holder located at the rear of the unit.	 <p>A technical line drawing of the rear of an indoor unit. A hand is shown using a screwdriver to remove a screw from a component labeled "Pipe Holder". A dashed line points from the label to the component. The drawing shows the internal structure of the unit, including pipes and electrical connections.</p>
2) Remove the screws (3) on the evaporator located on the fixed plate.	 <p>A technical line drawing showing a hand using a screwdriver to remove three screws from a fixed plate. Dashed lines point from the label "Screws" to the three screws being removed. The drawing shows the evaporator coils and the fixed plate they are attached to.</p>
3) Remove the screws (2) on the evaporator located at the base of the bearing side.	 <p>A technical line drawing showing a hand using a screwdriver to remove two screws from the base of the evaporator. Dashed lines point from the label "Screws" to the two screws being removed. The drawing shows the evaporator coils and the base of the bearing side.</p>

Indoor Unit Sizes 09K-12K (Evaporator) (continued)


Procedure	Illustration
4) Remove the screw (1) on the evaporator located at the top of the evaporator.	 A technical line drawing showing a hand using a screwdriver to remove a screw from the top edge of the evaporator coil. The evaporator is shown in its installed position within the indoor unit's casing.
5) Remove the evaporator.	 A technical line drawing showing the evaporator coil being lifted out of the indoor unit. A hand is shown at the bottom of the coil, and another hand is shown at the top. A dashed line points to the coil with the label "Evaporator". A large black arrow points upwards from the coil, indicating its removal from the unit.

Indoor Unit Sizes 09K-12K (Fan Motor and Fan)

NOTE: Remove the front panel, electrical parts and evaporator (refer to front panel, electrical parts, and evaporator removal steps) before disassembling fan motor and fan.


Procedure	Illustration
<p>1) Remove the screws (2) and remove the fixing board of the fan motor.</p>	 <p>The illustration shows a side view of the fan motor assembly. A hand is using a screwdriver to remove two screws from a metal fixing board. Dashed lines and arrows point to the screws, which are labeled 'Screws'.</p>
<p>2) Remove the bearing sleeve.</p>	 <p>The illustration shows a hand holding the fan motor while another hand removes a bearing sleeve from the motor shaft. Two black arrows indicate the direction of removal: one pointing right from the sleeve and one pointing up from the motor housing.</p>

Indoor Unit Sizes 09K-12K (Fan Motor and Fan) (continued)

Procedure	Illustration
<p>3) Remove the set screw.</p> <p>4) Pull out the fan motor and fan assembly from the side.</p>	 <p>The illustration shows a side view of the indoor unit's fan motor assembly. A hand is using a screwdriver to turn a set screw on the right side of the motor housing. An arrow points to the right, indicating the direction to pull the assembly out. A dashed line points to a screw on the bottom right, labeled 'Fixing Screw'.</p>


Indoor Unit Sizes 09K-12K (Step Motor)

NOTE: Remove the front panel and electrical parts (refer to the front panel, electrical parts removal steps) before disassembling the step motor.



Procedure	Illustration
<p>1) Remove the screws (2), then remove the stepping motor.</p>	 <p>The illustration shows a side view of the indoor unit's stepping motor. A hand is using a screwdriver to turn a screw on the bottom of the motor housing. A dashed line points to the motor, labeled 'Stepping Motor'.</p>

Indoor Unit Sizes 09K-12K (Occupancy Sensor)



NOTE: Remove the front panel and electrical parts (refer to the front panel, electrical parts, evaporator and fan motor and fan removal steps) before disassembling the occupancy sensor.

Procedure	Illustration
1) Remove the screw (1), then remove the Occupancy Sensor.	 <p>The illustration shows a hand using a screwdriver to remove a screw from the occupancy sensor. An arrow points upwards, indicating the direction of removal. The sensor is labeled "Occupancy Sensor".</p>



Indoor Unit Sizes 18K-24K (Front Panel)

Procedure	Illustration
<p>1) Hold the front panel by the tabs on both sides and lift it.</p>	 <p>The illustration shows a hand on the left side of the indoor unit, holding a tab. Another hand on the right side is also holding a tab. Both hands are lifting the front panel upwards. The front panel is shown in a hinged, open position. Labels 'Front Panel' and 'Tab' are present with dashed lines pointing to the respective parts.</p>
<p>2) Push up the bottom of the air filter (step 1), then pull it out downwards.</p>	 <p>The illustration shows a hand reaching into the indoor unit to push up the bottom edge of the air filter. A second arrow indicates the filter being pulled out downwards. The air filter is shown in a hinged, open position. Labels '1' and '2' are present with dashed lines pointing to the respective parts.</p>



Indoor Unit Sizes 18K-24K (Front Panel) (continued)

Procedure	Illustration
<p>3) Open the horizontal louver and push the hook towards the left to open it.</p>	 <p>The illustration shows a top-down view of the indoor unit's front panel with the horizontal louver open. A circular inset provides a magnified view of the louver's internal mechanism, showing a hand pushing a hook to the left. Labels 'Horizontal Louver' and 'Hook' are connected to their respective parts by dashed lines.</p>
<p>4) Bend the horizontal louver lightly with both hands to loosen the hooks, then remove the horizontal louver.</p>	 <p>The illustration shows the indoor unit with the horizontal louver being bent downwards by two hands, as indicated by black arrows. A circular inset shows a hand pulling the louver away from the unit, with a black arrow indicating the direction of removal. A label 'Hook' points to the internal mechanism.</p>




Indoor Unit Sizes 18K-24K (Front Panel) (continued)

Procedure	Illustration
<p>5) Pry the electrical cover with a screwdriver and rotate it towards the left, then remove it.</p>	
<p>6) Disconnect the connector on the display board.</p>	



Indoor Unit Sizes 18K-24K (Front Panel) (continued)

Procedure	Illustration
<p>7) Slide the front panel side to side to release each axis.</p>	
<p>8) Open the screw cap and then remove the screws (3).</p>	

Indoor Unit Sizes 18K-24K (Front Panel) (continued)



Procedure	Illustration
9) Release the hooks by hand.	 A line drawing showing a hand reaching into the front panel of an indoor unit. The hand is positioned to release a hook that is holding the panel in place. A large black arrow points upwards from the hook, indicating the direction of movement.
10) Release the 5 hooks in the back.	 A line drawing showing a hand reaching into the back of the front panel. The hand is positioned to release one of five hooks that are holding the panel to the heat exchanger. Two large black arrows point upwards from the hooks, indicating the direction of movement.
11) Pull out the panel frame, while pushing the hook through the clearance between the panel frame and the heat exchanger.	 A line drawing showing the front panel frame being pulled out of the indoor unit. Two hands are shown pulling the frame away from the heat exchanger. A large black arrow points to the right, indicating the direction of movement.

Indoor Unit Sizes 18K-24K (Front Panel) (continued)




Procedure	Illustration
<p>12) Release the 5 hooks of the vertical blades, then pull the vertical blades toward the right and remove them.</p>	 A line drawing showing a hand pulling a vertical blade from the front panel of the indoor unit. The blade is being moved from its original position towards the right side of the panel.
<p>13) Remove the display board's screw (1).</p> <p>14) Rotate the display board in the direction shown in the picture (on the right).</p>	 A line drawing showing a hand using a screwdriver to remove a screw from the display board. A curved arrow indicates the direction of rotation for the board. An inset circular image shows the display board with the screw removed and the board rotated.

Indoor Unit Sizes 18K-24K (Electrical Parts) (Anti-static gloves must be worn)



NOTE: Remove the front panel (refer to the front panel removal steps) before disassembling electrical parts.

Procedure	Illustration
<p>1) Cut the ribbon with a shear, then pull out the coil temperature sensor (T2).</p> <p>2) Remove the fixing screw (1) on the electronic control box and screws (2) used for the ground connection.</p>	 <p>The illustration shows a hand pulling out a ribbon from the electronic control box. A label 'Ground Screws' points to screws on the top of the box. A circular inset shows a hand using shears to cut the ribbon, with a label 'Ribbon' pointing to the cut. Another circular inset shows a hand pulling out the T2 sensor, with a label 'T2 Sensor' pointing to it.</p>
<p>3) Pull upwards until the electronic control box cover is removed.</p>	 <p>The illustration shows a hand pulling upwards on the electronic control box cover, indicated by an upward arrow.</p>



Indoor Unit Sizes 18K-24K (Electrical Parts) (Anti-static gloves must be worn) (continued)

Procedure	Illustration
<p>4) Remove the fixed devices from the connectors.</p>	 <p>The illustration shows a pair of hands using a small tool to lift a component from a connector on a printed circuit board. A circular inset provides a magnified view of the component being lifted, with an upward-pointing arrow indicating the direction of removal.</p>
<p>5) Disconnect the fan motor connectors, the step motor and the T2 sensor.</p>	 <p>The illustration shows a pair of hands pulling three different connectors out of their respective ports on the electronic control box. An upward-pointing arrow indicates the direction of disconnection.</p>
<p>6) Open the left side plate of the electronic control box.</p>	 <p>The illustration shows a pair of hands lifting the left side plate of the electronic control box. An upward-pointing arrow indicates the direction of movement.</p>



Indoor Unit Sizes 18K-24K (Electrical Parts) (Anti-static gloves must be worn) (continued)

Procedure	Illustration
<p>7) Open the two clips on the front of the electric box.</p>	 A perspective view of a rectangular electric control box. The top surface is a light gray color, and the front and side panels are white. Two clips on the front edge are highlighted with dashed circles, indicating they are to be opened.
<p>8) Open the upper cover plate of the electronic control box.</p>	 A close-up illustration showing a pair of hands manipulating the front of the electric box. The hands are shown in a light gray tone. One hand is holding the front panel, and the other is pulling a small, dark-colored cover plate away from the front. A black arrow points to the right, indicating the direction of movement for the cover plate. Several wires are visible extending from the bottom of the box.




Indoor Unit Sizes 18K-24K (Electrical Parts) (Anti-static gloves must be worn) (continued)

Procedure	Illustration
<p>9) Remove the screw (1) and open the 2 clips along the direction indicated in the image on the right side.</p>	
<p>10) Pull out the electrical main board along the direction indicated in the image on the right.</p>	

Indoor Unit Sizes 18K-24K (Evaporator)



Procedure	Illustration
<p>1) Disassemble the pipe holder located at the rear of the unit.</p>	
<p>2) Remove the screw (1) on the evaporator located at the fixed plate.</p>	

Indoor Unit Sizes 18K-24K (Evaporator) (continued)


Procedure	Illustration
3) Release the hook on the evaporator.	 A line drawing showing a hand using a screwdriver to pry a hook on the evaporator coil. An inset circle shows a close-up of the hook being released from the coil.
4) Remove the screw (1) on the evaporator located at the fixed plate.	 A line drawing showing a hand using a screwdriver to remove a screw from the evaporator coil. The screw is labeled with the number '1'.
5) Remove the evaporator.	 A line drawing showing the evaporator coil being lifted out of the unit. An upward-pointing arrow indicates the direction of removal.

Indoor Unit Sizes 18K-24K (Fan Motor and Fan)

NOTE: Remove the front panel, electrical parts and evaporator (refer to front panel, electrical parts, and evaporator removal steps) before disassembling fan motor and fan.


Procedure	Illustration
<p>1) Remove the screws (2) and remove the fixing board of the fan motor.</p>	 <p>The illustration shows a side view of the fan motor assembly. A hand is using a screwdriver to remove two screws from a metal fixing board that is attached to the motor. Dashed lines indicate the location of the screws. The label 'Screws' is positioned at the bottom right of the illustration.</p>
<p>2) Remove the bearing sleeve.</p>	 <p>The illustration shows a hand holding the fan motor while another hand uses a tool to remove a bearing sleeve from the motor's shaft. Two black arrows point to the right, indicating the direction of removal for the sleeve.</p>

Indoor Unit Sizes 18K-24K (Fan Motor and Fan) (continued)

Procedure	Illustration
<p>3) Remove the set screw.</p> <p>4) Pull out the fan motor and fan assembly from the side.</p>	 <p>The illustration shows a side view of the indoor unit's fan motor assembly. A hand is using a screwdriver to turn a set screw on the right side of the motor housing. A dashed line points to a screw on the bottom of the unit labeled "Fixing Screw".</p>

Indoor Unit Sizes 18K-24K (Step Motor)

NOTE: Remove the front panel and electrical parts (refer to the front panel, electrical parts removal steps) before disassembling the step motor.

Procedure	Illustration
<p>1) Remove the screws (2), then remove the stepping motor.</p>	 <p>The illustration shows a side view of the indoor unit's stepping motor. A hand is using a screwdriver to turn a screw on the bottom of the motor housing. A dashed line points to the motor housing labeled "Stepping Motor".</p>

APPENDICES

Appendix 1

Table 20 — Temperature Sensor Resistance Value Table for T1, T2, T3, T4 (C--K)

°C	°F	K OHM	°C	°F	K OHM	°C	°F	K OHM	°C	°F	K OHM
-20	-4	115.266	20	68	12.6431	60	140	2.35774	100	212	0.62973
-19	-2	108.146	21	70	12.0561	61	142	2.27249	101	214	0.61148
-18	0	101.517	22	72	11.5	62	144	2.19073	102	216	0.59386
-17	1	96.3423	23	73	10.9731	63	145	2.11241	103	217	0.57683
-16	3	89.5865	24	75	10.4736	64	147	2.03732	104	219	0.56038
-15	5	84.219	25	77	10	65	149	1.96532	105	221	0.54448
-14	7	79.311	26	79	9.55074	66	151	1.89627	106	223	0.52912
-13	9	74.536	27	81	9.12445	67	153	1.83003	107	225	0.51426
-12	10	70.1698	28	82	8.71983	68	154	1.76647	108	226	0.49989
-11	12	66.0898	29	84	8.33566	69	156	1.70547	109	228	0.486
-10	14	62.2756	30	86	7.97078	70	158	1.64691	110	230	0.47256
-9	16	58.7079	31	88	7.62411	71	160	1.59068	111	232	0.45957
-8	18	56.3694	32	90	7.29464	72	162	1.53668	112	234	0.44699
-7	19	52.2438	33	91	6.98142	73	163	1.48481	113	235	0.43482
-6	21	49.3161	34	93	6.68355	74	165	1.43498	114	237	0.42304
-5	23	46.5725	35	95	6.40021	75	167	1.38703	115	239	0.41164
-4	25	44	36	97	6.13059	76	169	1.34105	116	241	0.4006
-3	27	41.5878	37	99	5.87359	77	171	1.29078	117	243	0.38991
-2	28	39.8239	38	100	5.62961	78	172	1.25423	118	244	0.37956
-1	30	37.1988	39	102	5.39689	79	174	1.2133	119	246	0.36954
0	32	35.2024	40	104	5.17519	80	176	1.17393	120	248	0.35982
1	34	33.3269	41	106	4.96392	81	178	1.13604	121	250	0.35042
2	36	31.5635	42	108	4.76253	82	180	1.09958	122	252	0.3413
3	37	29.9058	43	109	4.5705	83	181	1.06448	123	253	0.33246
4	39	28.3459	44	111	4.38736	84	183	1.03069	124	255	0.3239
5	41	26.8778	45	113	4.21263	85	185	0.99815	125	257	0.31559
6	43	25.4954	46	115	4.04589	86	187	0.96681	126	259	0.30754
7	45	24.1932	47	117	3.88673	87	189	0.93662	127	261	0.29974
8	46	22.5662	48	118	3.73476	88	190	0.90753	128	262	0.29216
9	48	21.8094	49	120	3.58962	89	192	0.8795	129	264	0.28482
10	50	20.7184	50	122	3.45097	90	194	0.85248	130	266	0.2777
11	52	19.6891	51	124	3.31847	91	196	0.82643	131	268	0.27078
12	54	18.7177	52	126	3.19183	92	198	0.80132	132	270	0.26408
13	55	17.8005	53	127	3.07075	93	199	0.77709	133	271	0.25757
14	57	16.9341	54	129	2.95896	94	201	0.75373	134	273	0.25125
15	59	16.1156	55	131	2.84421	95	203	0.73119	135	275	0.24512
16	61	15.3418	56	133	2.73823	96	205	0.70944	136	277	0.23916
17	63	14.6181	57	135	2.63682	97	207	0.68844	137	279	0.23338
18	64	13.918	58	136	2.53973	98	208	0.66818	138	280	0.22776
19	66	13.2631	59	138	2.44677	99	210	0.64862	139	282	0.22231

Appendix 2

Table 21 — Temperature Sensor Resistance Value Table for TP (T5)

° C	° F	K OHM	° C	° F	K OHM	° C	° F	K OHM	° C	° F	K OHM
-20	-4	542.7	20	68	68.66	60	140	13.59	100	212	3.702
-19	-2	511.9	21	70	65.62	61	142	13.11	101	214	3.595
-18	0	483	22	72	62.73	62	144	12.65	102	216	3.492
-17	1	455.9	23	73	59.98	63	145	12.21	103	217	3.392
-16	3	430.5	24	75	57.37	64	147	11.79	104	219	3.296
-15	5	406.7	25	77	54.89	65	149	11.38	105	221	3.203
-14	7	384.3	26	79	52.53	66	151	10.99	106	223	3.113
-13	9	363.3	27	81	50.28	67	153	10.61	107	225	3.025
-12	10	343.6	28	82	48.14	68	154	10.25	108	226	2.941
-11	12	325.1	29	84	46.11	69	156	9.902	109	228	2.86
-10	14	307.7	30	86	44.17	70	158	9.569	110	230	2.781
-9	16	291.3	31	88	42.33	71	160	9.248	111	232	2.704
-8	18	275.9	32	90	40.57	72	162	8.94	112	234	2.63
-7	19	261.4	33	91	38.89	73	163	8.643	113	235	2.559
-6	21	247.8	34	93	37.3	74	165	8.358	114	237	2.489
-5	23	234.9	35	95	35.78	75	167	8.084	115	239	2.422
-4	25	222.8	36	97	34.32	76	169	7.82	116	241	2.357
-3	27	211.4	37	99	32.94	77	171	7.566	117	243	2.294
-2	28	200.7	38	100	31.62	78	172	7.321	118	244	2.233
-1	30	190.5	39	102	30.36	79	174	7.086	119	246	2.174
0	32	180.9	40	104	29.15	80	176	6.859	120	248	2.117
1	34	171.9	41	106	28	81	178	6.641	121	250	2.061
2	36	163.3	42	108	26.9	82	180	6.43	122	252	2.007
3	37	155.2	43	109	25.86	83	181	6.228	123	253	1.955
4	39	147.6	44	111	24.85	84	183	6.033	124	255	1.905
5	41	140.4	45	113	23.89	85	185	5.844	125	257	1.856
6	43	133.5	46	115	22.89	86	187	5.663	126	259	1.808
7	45	127.1	47	117	22.1	87	189	5.488	127	261	1.762
8	46	121	48	118	21.26	88	190	5.32	128	262	1.717
9	48	115.2	49	120	20.46	89	192	5.157	129	264	1.674
10	50	109.8	50	122	19.69	90	194	5	130	266	1.632
11	52	104.6	51	124	18.96	91	196	4.849			
12	54	99.69	52	126	18.26	92	198	4.703			
13	55	95.05	53	127	17.58	93	199	4.562			
14	57	90.66	54	129	16.94	94	201	4.426			
15	59	86.49	55	131	16.32	95	203	4.294			
16	61	82.54	56	133	15.73	96	205	4.167			
17	63	78.79	57	135	15.16	97	207	4.045			
18	64	75.24	58	136	14.62	98	208	3.927			
19	66	71.86	59	138	14.09	99	210	3.812			

Appendix 3

Table 22 — Celsius to Fahrenheit

°C	°F	°C	°F	°C	°F	°C	°F	°C	°F
-5	23	21	69.8	51	123.8	82	179.6	113	235.4
-4	24.8	22	71.6	52	125.6	83	181.4	114	237.2
-3	26.6	23	73.4	53	127.4	84	183.2	115	239
-2	28.4	24	75.2	54	129.2	85	185	116	240.8
-1	30.2	25	77	55	131	86	186.8	117	242.6
0	32	25.5	77.9	56	132.8	87	188.6	118	244.4
0.5	32.9	26	78.8	57	134.6	88	190.4	119	246.2
1	33.8	27	80.6	58	136.4	89	192.2	120	248
1.5	34.7	28	82.4	59	138.2	90	194	121	249.8
2	35.6	29	84.2	60	140	91	195.8	122	251.6
2.5	36.5	30	86	61	141.8	92	197.6	123	253.4
3	37.4	31	87.8	62	143.6	93	199.4	124	255.2
3.5	38.3	32	89.6	63	145.4	94	201.2	125	257
4	39.2	33	91.4	64	147.2	95	203	126	258.8
4.5	40.1	34	93.2	65	149	96	204.8	127	260.6
5	41	35	95	66	150.8	97	206.6	128	262.4
6	42.8	36	96.8	67	152.6	98	208.4	129	264.2
7	44.6	37	98.6	68	154.4	99	210.2	130	266
8	46.4	38	100.4	69	156.2	100	212	131	267.8
9	48.2	39	102.2	70	158	101	213.8	132	269.6
10	50	40	104	71	159.8	102	215.6	133	271.4
11	51.8	41	105.8	72	161.6	103	217.4	134	273.2
12	53.6	42	107.6	73	163.4	104	219.2	135	275
13	55.4	43	109.4	74	165.2	105	221	136	276.8
14	57.2	44	111.2	75	167	106	222.8	137	278.6
15	59	45	113	76	168.8	107	224.6	138	280.4
16	60.8	46	114.8	77	170.6	108	226.4	139	282.2
17	62.6	47	116.6	78	172.4	109	228.2	140	284
18	64.4	48	118.4	79	174.2	110	230	141	285.8
19	66.2	49	120.2	80	176	111	231.8	142	287.6
20	68	50	122	81	177.8	112	233.6	143	289.4

